Specification

Model	SMC-S200MT20C		
Pick up Element	1/2.8" SONY 2.4MP CMOS Sensor		
Effective Picture Elements (H×V)	1920 X1080		
Resolution	1080P		
Minimum Illumination	0.001 Lux/F1.2		
S/N Ratio	More than 50dB		
Synchronous System	Internal, Negative sync.		
IR Distance	20 Meters (with Φ5X21 PCS Infrared LED)		
IR Power On	Photodiode AUTO Control		
Video Output	CVI		
Functions	DNR,UTC		
Power/Current	DC12V(+/-10%)/500mA		
Lens	2.8-12mm Manual Zoom Lens		
IP Rating	IP66		
Dimension (mm)	Ф151x 108(H)		
Weight (g)	1200		
Operating Tempera- ture	-10~+50 RH95% MAX		


Accessories list

Name	Number
Camera	1
User Guide	1

Notes:

Do not attempt to disassemble the camera. If the camera can not work, please contact local franchiser or our company.

CCTV Camera



Plastic IR Dome Camera



Thank you for using our product. Before providing power for the camera, please read this manual carefully before use.

We adopt the latest technical of sensor and driver. It owns the characters of high definition and stability, strong anti-jamming, rich and real color. Fixing and using this model are convenient too. It is very good for you to apply to your CCTV system.

Main Features

> Auto Gain Control (AGC)

Built-in auto gain control **(AGC)** circuit. The color camera can get high definition picture in low Lux condition.

> Auto Electronic Shutter (AES)

Built-in auto electronic shutter function. The color camera's AES speed can reach 1/100,000s.

> Gama Characteristic

Camera Gama characteristic is 0.45.


> Scanning Mode

NTSC or PAL mode.

> OSD MENU

AE	BRIGHTNESS	256-1024 (512)		
	AE MODE	NORMAL		
		BACK LIGHT		
		FRONT LIGHT		
	RETURN			
WB	AUTO			
	GRAY WORLD			
DAY&NIGHT	EXTERN			
	INTERNAL			
	COLOR			
	MONO			
VIDEO SET- TING	VIDEO	PAL/NTSC		
	NR	2D-NR	OPEN/CLOSE	
		Y-NR	OPEN/CLOSE	
		C-NR	OPEN/CLOSE	
	RETURN			
LANGUAGE	ENGLISH/CHINESE			
RESET				
SAVE&EXIT				
EXIT				

Device connection



Safety instruction

- 1.Before using the camera ,please read this manual carefully and keep it safely for later use.
- 2.Installation should be proceed by professional service and follow manufacturer's instructions, do not dismantle without authoriza tion.
- 3.In order to prevent sensor ,do not expose lens to intense light source in long time.
- 4.Do not touch sensor directly. Please covers the dustproof cover when the camera is not being used.
- 5.Please use a dry soft cloth to clean the camera. If dirt difficult to clean, use detergent with water and wipe dry the camera.
- 6.Do not install camera under air conditioning's air gate ,or else lens blur with condensation of moisture.
- 7.Please ensure that all electric power sources are turned off when not open , installation ,clean, etc operation.
- 8.Please transporting , using and storing the camera in allowable temperature and humidity.
- 9.If the camera was broken, for example power cord or plug damaged,Splash liquid or foreign matter fall into camera, raining, wetting, etc can't work situation, please contact manufacturer or maintenance center (modify and maintenance without perm ission, you must be responsible for the problems).

Common Problems and Troubleshooting

> No Picture after providing power

May be the power supply voltage abnormity, please check he power supply voltage and pole whether exactitude. Please check all the connecting cable and monitors whether be connected correctly or not.

> The picture level direction have flowing interference ripples

May be caused by the power supply AC ripples, it need filter the wave of the power supply.

Check the monitor and peripheral equipments used.

- > The picture background color changes continuously The fluorescent lamp's electromagnetic field cause color roll. This is proper phenomenon of the cameras. Reduce the fluorescent lamp numbers or increase the distance between the camera and the fluorescent lamps can improve it.
 - Use power supply external sync. camera can solve it.
- > The picture smear too mass

The power supply's voltage unstable. Connecting cables not connect correctly or have high impedance.



- Power supply must pass safety certification , Its output voltage, current, voltage polarity and operating temperature must match requirement of this equipment.
- Please install lightning protection devices or cut off the power in thunder and lightning conditions.
- To capture high-quality video and pictures, please make sure the network connection is stable and smooth.
- Please note the camera's operating temperature and its using environment requirement. Avoid using the camera at too high or too low temperatures. The operating tem-

perature is -30~+60 °C. (Recommendatory operating tem-

perature is -10~+50 °C.)

• Do not mount the camera near by the radiator or heater.